

FE 257 LAB 8

Raster Data Applications

Watershed Delineation


In this lab you will continue to familiarize yourself with raster data structures and the Spatial Analyst. The datasets for this lab are drawn from one of the sample databases in the text, “Geographic Information Systems: Applications in Forestry and Natural Resource Management.” The datasets represent a fictional area named the Brown Tract and are well suited for our lab applications.

Open the Windows Explorer and navigate to the t:\teach\classes\fe257\gislab8 location on the forestry network. Right click on this folder and choose Copy from the menu that appears. Use Windows Explorer to navigate to your workspace folder. For most of you this will be located on the N:\ drive and will have the same name as your user name- for me it's N:\wingm. Right click on your FE257 workspace folder and choose Paste from the menu that appears. This should copy the gislab8 folder and all its nested folders and files into your workspace.

Start a new ArcGIS Pro session and select New Blank Map. Save your map document as Lab8.aprx and store it under your workspace\gislab8 folder.

If necessary, go to Insert > Add Folder to connect to your workspace\gislab8 folder. Use the Add Data button to add boundary.shp and streams.shp to your map. You can adjust the symbology of the layers to match your preferences. Rename your data frame “Watershed” and save your map project.


All distance and elevation units in the Lab 8 datasets are U.S. feet (survey feet).



Importing Raster Files

We'll need to access the Brown Tract DEM. The pixels in the Brown Tract DEM represent elevation values for each 10m per side “square” within the forested area of interest.

Add the BrownTractDEM file to your Map session. Rename this layer “Brown Tract DEM” in your Contents window.



Spatial Analyst

For this lab we will use geoprocessing tools available through the Spatial Analyst extension. Like in Lab 7, you can go to Project > Licensing to check for the extension.

Esri Extensions

Name	Licensed	Expires
Location Referencing	Yes	8/1/2020
Maritime Bathymetry	No	N/A
Maritime Charting	Yes	8/1/2020
Network Analyst	Yes	8/1/2020
Production Mapping	Yes	8/1/2020
Publisher	Yes	8/1/2020
Spatial Analyst	Yes	8/1/2020
StreetMap Premium Asia Pacific	No	N/A
StreetMap Premium Europe	No	N/A

Watershed Delineation

A watershed is defined as an area that shares a common drainage. For a variety of management purposes, foresters are often asked to define and measure watershed areas. Watershed boundaries and measurements are used to estimate overland flow, identify landslide-prone sites, and to split landscapes into hydrologic regions of influence.


The definition of a watershed boundary will be a function of landscape slope and aspect; the basic components of topography. For many years, foresters were limited to working with hardcopy topographic maps or their own field observations to define watershed areas. With the availability of 10 and 30m resolution DEMs for the entire U.S. and

modern GIS capabilities, we can compute watershed boundaries and areas much more quickly, and potentially much more accurately.


In this lab you will use the Brown Tract DEM to create a watershed boundary following two different methods. The first method will involve heads-up delineation of a watershed boundary. This heads-up method will require you, the user, to evaluate contour lines and available spatial databases to guide your expertise in digitizing a watershed boundary. The second method will take advantage of some of the automated raster processing tools available through the Spatial Analyst. We'll then compare the results of these two methods. The Brown Tract is our area of interest.

Using Elevation Contours and Other Spatial Data to Locate a Watershed Boundary


The Streams layer within the Brown Tract has several components to it. We're going to focus our initial efforts on a stream stem in the southwest portion. We'll first select the stream sections we're interested in, then we'll convert those sections into a separate layer. As a first step, make the Streams layer the only selectable layer. Right click on Streams > Selection > Make this the only selectable layer. You can also use the List by Selection tab in the Contents window to make sure that only the Streams layer is checked under "Selection."



The graphic below shows the stream sections of interest for the lab exercise in the southwest corner of the boundary area. Zoom in to the same spatial extent as the graphic and use the Select tool to select these stream sections. Holding the Shift key will allow you to select multiple features with different mouse clicks.




Once you select these sections, switch back to the List by Drawing Order tab in your Contents window.




Create a new shapefile containing the stream sections you selected.

1. Right click on the Streams layer in the Contents window.
2. Select Data > Export Features.
3. In the Export Features dialog box, make the Input Features Streams and save the output to your gislab8 folder as SW_streams.shp. Click Run.



Rename the new layer SW Streams and adjust its symbology so you can see it clearly. If necessary, turn off the Streams layer and right click on SW Streams in the Contents window and select Zoom to Layer. Click Clear in the Selection menu.


Turn the Boundary layer off.




Creating Elevation Contours

You will now heads-up digitize a watershed area for the SW Streams layer. The initial step in this process will be to create elevation contours guiding our digitizing.

1. In the Geoprocessing window, search for the Contour tool like in Lab 7.
2. This will open the Contour dialog box. Set the Contour Interval to 40 (to mimic a USGS 7.5' topographic map) and save the output as contour40.shp to your gislab8 folder. Click Run.




The contour40 layer should appear in your map and the Contents window.



Heads-Up Watershed Delineation

Examine the output and its relation to the SW streams layer. Use the contours, stream network of interest, and surrounding stream networks to guide your process of delineating a watershed. If you examine each of these layers in your map frame, you'll notice that the contour shapes create V's that usually define flow paths and directions. Typically, water flows from the bottom point of the V shape to the top (ridge to valley, high to low elevation). Saddle shapes (contour lines that look like ovals or circles) usually indicate ridge lines and can sometimes be used to define the boundary between watersheds.

We can also use surrounding stream network sections to help identify the ridge line that divides one watershed from another. Turn the Streams layer back on and change its Symbology to help differentiate between SW Streams and Streams like in the graphic below. Evaluate your data layers to determine where the ridges surround your watershed.




If you're uncertain about defining a portion of a watershed boundary, think about which direction water would flow if you dumped a bucket of water on the uncertain location. This may help you place a watershed boundary line. Using these topographic clues and approaches, we should be able to heads-up digitize a watershed for the SW streams layer.


Start by locating the lowest section of the SW streams layer where it flows into the main stem - this is where we'll begin our watershed. Try to visualize, from this starting location, where you would draw the watershed boundary line. Make sure you are zoomed out far enough to see all the sections of the layers you'll need. This includes the stream sections of the network to the north of the SW Streams layer.


You will first create a new polygon feature class to store the heads-up watershed polygon you draw. First, make sure you have established a folder connection to your gislab8 folder (Insert menu > Add Folder). In the Catalog window, right click on the gislab8 folder and select New > Shapefile.

The Create Feature Class dialogue box should open. Navigate to your gislab8 workspace under Feature Class Location. The Feature Class Name will be SW_Streamshed. Geometry Type is Polygon. Leave all other defaults except for Coordinate System; in the drop-down menu, select Current Map [Watershed] and the field will populate with NAD 1927. Click Run.





The SW_Streamshed polygon feature class should appear in your Contents window; rename it "SW Streamshed." If you open the attribute table, you'll notice the feature class doesn't contain any features because we haven't created any yet. Drawing our heads-up watershed polygon will create a polygon feature in the feature class.







You will now use the Create Features window to digitize your heads-up watershed polygon. Go to the Edit menu > Create. This will open the Create Features window displaying all the templates for editable feature layers in your map project. We are only concerned with the SW Streamshed layer.



Click on the SW Streamshed template to expand it and open the Active Template menu. Click the Polygon icon to begin drawing a polygon around the watershed area.




Once you've activated the Polygon tool, your cursor will enable you to draw a polygon by single clicking around the watershed in your map display area. Each subsequent click establishes a turning point, or vertex, for your polygon. When you approach the spot where you began drawing your polygon, a double click will close the polygon. Digitize your watershed using this tool and the delineation instructions provided above.




After you've used the Polygon tool to draw a watershed polygon, you can use the Edit Vertices tool and Modify Features window to adjust the shape if necessary.







- Move a vertex by clicking it and dragging it.
- Add a new vertex by right clicking on the edge of the polygon and selecting Add Vertex.
- An existing vertex can be removed by right clicking on a vertex and selecting Delete Vertex.
- You can delete the entire polygon by using the Select tool to select it and right clicking > Delete.

When you're finished digitizing, save your edits in the Edit menu. Save your map project as well.



Adjust the watershed Symbology if necessary. If preferred, you can adjust the transparency of SW Streamshed by clicking on the layer in the Contents window and going to the Feature Layer > Appearance menu. Use the transparency slider to adjust the transparency to your liking.



Updating Watershed Area Measurements

As always, when we create or edit a shapefile, we must update the area measurements (polygon area, line length, etc.) Use the Calculate Geometry tool for this purpose.

The adding or updating of measurements is something you should do to a layer every time you create a new polygon or line layer, or change the dimensions (size) of an existing polygon or line layer.

Let's add area measurements to the SW Streamshed layer.

1. Open the SW Streamshed attribute table. Click the Add Field button.
2. Under Field Name, type Area. Leave all other defaults and click Save. An Area field should appear in the SW Streamshed attribute table.

Visible	Read Only	Field Name	Alias	Data Type	Allow NULL	Highlight	Number Format	Default	Precision	Scale	Length
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	FID	FID	Object ID	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		0	0	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	Shape	Shape	Geometry	<input type="checkbox"/>	<input type="checkbox"/>			0	0	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	Id	Id	Long	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		6	0	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	Area	Area	Long	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		10	0	

FID	Shape	Id	Area
0	Polygon	0	0

- Right click on the new area field and select Calculate Geometry.
- In the Calculate Geometry window, the Input Features are SW Streamshed. The Target Field is Area and the Property is Area. Change the Area Unit to Acres; in the future you can change the Area Unit to whatever suits your application. Click Run.

Geoprocessing

← Calculate Geometry Attributes →

Parameters Environments ?

Input Features
SW Streamshed

Geometry Property
Target Field Property
Area Area

Area Unit
Acres

Coordinate System

Your area calculation should produce a value of roughly 860 acres. If your value is slightly above or below this number, this is to be expected; no two students' area calculations will be the same since each individual drew a unique polygon. As long as your polygon shape looks roughly correct and your value is in the mid to high 800s, your steps were correct.

FID	Shape	Id	Area
0	Polygon	0	860

Close the attribute table. Save your map project.

Using a DEM to Automate Watershed Delineation


In this portion of the lab, we'll let the Brown Tract DEM do some of the work for us in watershed delineation. While the DEM will provide information about changes in elevation from one pixel to another, we'll mine this information for data regarding the **direction** in which water would flow over the landscape. We'll use the Flow Direction tool for this task.

The Flow Direction tool systematically assesses the entire DEM raster using a moving window surrounding sets of pixels. The tool compares differences in elevation between pixels within the window. It keeps track of the differences in values to determine which pixels are the downslope neighbors of others. Using this information, ArcGIS Pro computes a flow direction raster where each pixel represents the expected direction water will flow across the landscape based on elevation differences between pixels and their downslope neighbors. The following ArcGIS Pro documentation (ESRI) conceptualizes the D8 flow direction model, which we will use in the next step:


The D8 flow option models flow direction from each pixel to its steepest downslope neighbor. All of the flow is directed to this steepest neighbor. The output of the **D8** direction type is an integer raster whose values range from 1 to 255. The values for each direction from the center are shown in the following image:

32	64	128
16		1
8	4	2


For example, if the direction of steepest drop was to the left of the current processing pixel, its flow direction would be coded as 16. The example below shows how elevation values are converted to flow direction codes.




Search for Flow Direction in the Geoprocessing Window.



In the Flow Direction dialogue box, make the Input Surface Raster Brown Tract DEM. Save the Output Flow Direction Raster to your gislab8 folder as FlowDirBrown. Leave all other defaults; we will use the D8 Flow Direction Type featured in the above ArcGIS Pro documentation. Click Run.




The FlowDirBrown raster should appear in your Contents window. You should now have a flow direction raster for the entire Brown Tract DEM. Examine the results. As stated in the D8 flow direction model documentation, the raster is classified into nine categories based on elevation differences between pixels. The pixel colors and patterns should generally reflect the landscape topography made clear through the DEM shading and contour lines.




Save your map project.

You will now use the Watershed tool to create a computer-automated watershed delineation based on your new flow direction raster. Search for Watershed in the Geoprocessing window.




Look at the Watershed dialogue box; you will notice we have a problem. We need both a flow direction raster and an input raster to generate a watershed.




We currently have our flow direction raster but no input raster. We must first create an input raster to successfully run the Watershed tool. The input raster will be the location for which to calculate a watershed, aka our SW Streams layer. However, our SW Streams layer is in a vector format. We'll use some Spatial Analyst tools to convert this file into a raster format that will serve as our input raster for the Watershed tool.


First, we will modify Raster Analysis options in the Geoprocessing Environment settings to ensure that the new output raster file will meet our needs. Go to the Analysis menu > Environments.



In the Environments dialogue box, find the Raster Analysis section.



Under Cell Size heading, click the drop down and select “Same as layer Brown Tract DEM.” Leave all other defaults and click OK. This ensures that the raster we create from SW Streams will have the same cell size as Brown Tract DEM.



Now you’ll convert the SW Streams layer to a raster data structure as needed for the Watershed tool. First, create a new field in the SW Streams attribute table containing the same value for all stream features.


Open the attribute table for SW Streams and click Add Field. Under Field Name, type SW. Data Type will be Short and Precision will be 2. Leave all other defaults and click Save.

Visible	Read Only	Field Name	Alias	Data Type	Allow NULL	Highlight	Number Format	Default	Precision	Scale	Length
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	FID	FID	Object ID	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		0	0	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	Shape	Shape	Geometry	<input type="checkbox"/>	<input type="checkbox"/>			0	0	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	LENGTH	LENGTH	Double	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		17	5	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	STREAM	STREAM	Double	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		11	0	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	BUFFER	BUFFER	Double	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		16	0	
<input checked="" type="checkbox"/>	<input type="checkbox"/>	FISHBEARIN	FISHBEARIN	Text	<input type="checkbox"/>	<input type="checkbox"/>			0	0	16
<input checked="" type="checkbox"/>	<input type="checkbox"/>	SIZE	SIZE	Text	<input type="checkbox"/>	<input type="checkbox"/>			0	0	16
<input checked="" type="checkbox"/>	<input type="checkbox"/>	SW	SW	Short	<input type="checkbox"/>	<input type="checkbox"/>	Numeric		2	0	

A new field called SW should now exist in your SW Streams attribute table.

FID	Shape	LENGTH	STREAM	BUFFER	FISHBEARIN	SIZE	SW
0	Polyline	547.35064	74	20	No	Small	0
1	Polyline	585.50177	76	20	No	Small	0
2	Polyline	1101.02001	77	20	No	Small	0


Right click on the SW field header and select Calculate Field. Enter 1 in the “SW =” box and click Run. Now check the SW Streams attribute table to see that every cell in the SW column is populated with 1. Close the attribute table.




FID	Shape	LENGTH	STREAM	BUFFER	FISHBEARIN	SIZE	SW
0	Polyline	547.35064	74	20	No	Small	1
1	Polyline	585.50177	76	20	No	Small	1
2	Polyline	1101.02001	77	20	No	Small	1
3	Polyline	271.98617	82	20	No	Small	1
4	Polyline	2147.10884	83	20	No	Small	1
5	Polyline	870.37017	84	20	No	Small	1
6	Polyline	743.82784	85	20	No	Small	1

Create a Raster File of SW Streams


In the Geoprocessing window, search for Feature to Raster.



In the Feature to Raster dialog box, make SW Streams the Input Features. The Field will be SW. Direct the output to your gislab8 folder and name it sw_strm_grid. The Output Cell Size should automatically populate with the Brown Tract DEM file since we set those parameters earlier in the Environments menu. Click Run.




The output should be added to your Contents window. Zoom to the extent of the SW Streamshed layer and turn off all layers except the Brown Tract DEM and new raster layer sw_strm_grid. Rename the new layer SW Streams Grid. You should see that the vector SW Streams layer was converted to raster pixels overlaying those in the Brown Tract DEM.




We now have all the files to create a computer-automated watershed delineation with the Watershed tool. Again, search for Watershed in the Geoprocessing window.

In the Watershed dialogue box, make FlowDirBrown the Input D8 Flow Direction Raster. The Input Raster is SW Streams Grid. The Pour Point Field is VALUE. Save the output to your gislab8 folder with the name sw_strm_gshed. Click Run.




Examine the results. Turn the SW Streams layer on so you can see the streams of interest. Turn the contour40 layer on to see how well the computer recognized topography. Turn the SW Streamshed layer on to compare the computer-digitized results to your heads-up digitizing results. When finished organizing your layers they should look like this:




Which digitization method more accurately represents the SW Streams Watershed? Consider the strengths and weaknesses of both methods. Save your map project.


Use the Raster to Polygon tool to convert the new sw_strm_gshed raster file to a vector polygon feature. Search for Raster to Polygon in the Geoprocessing window.




In the Raster to Polygon dialogue box, make sw_strm_gshed the Input Raster. The Field is VALUE. Direct the Output Polygon Features to your gislab8 folder with the name sw_strm_wshed2.shp. Click Run.



The new polygon layer will appear in your Contents window. It should directly overlay the sw_strm_gshed raster. **Do not rename the layer or else your future area calculation will not work!** Save your map project.



Now calculate the area of your computer-delineated watershed and compare it to your heads-up digitized version. Follow the same steps as before on Pages 11-12 to complete this task. The area of the DEM-derived watershed should be about 810 acres.



The screenshot shows a window titled 'sw_strm_wshed2'. Below the title bar is a toolbar with 'Field:' and 'Selection:' sections. The 'Field:' section contains 'Add' and 'Calculate' buttons. The 'Selection:' section contains a 'Zoom' button. Below the toolbar is a table with the following data:


FID	Shape	Id	gridcode	Area
0	Polygon	1	1	810

Finish the lab exercise by preparing a new data frame for your lab assignment called Watershed 2. You have the option to delete the files you created in the lab exercise using the Catalog window. These files may confound your data management abilities for the lab assignment; however, you may want to use some of them for your assignment analyses (like the flow direction raster) instead of creating completely new files.

Save your map project.

Lab 8 Application. This is a team assignment. Please include your names and lab day and time (e.g. Tuesday 10 AM) on your submission. This lab is due at the beginning of next week's lab.

Use both the heads-up digitizing AND DEM-based (computer digitized) watershed delineation methods presented in this lab to generate two watershed delineations for the following set of streams in the Brown Tract:



Create map of your two watershed results. The map should contain both your heads-up digitized watershed and the computer-created watershed; the polygons should overlap. You can use the transparency slider to display both at the same time if you wish, or leave them solid colored since one polygon should be smaller than the other. **All other map elements for a quality map should also be present!** 6 points.